

How to Use Novo-Dry Cargo

Novo-Dry Cargo has been laboratory tested and shown to significantly reduce relative humidity in an airtight space when used properly. If you have used other desiccants previously for cargo containers, Novo-Dry will follow similar care instructions.

Recommendations to achieve optimal performance:

- **Similar to other desiccants, Novo-Dry must remain the sealed Ziplock kit until ready to use and always quickly resealed if not utilizing the entire kit.**
- Novo-Dry Cargo is most effective in a sealed container. The space that Novo-Dry is protecting must be kept airtight. All container air vents must be sealed with duct tape before closing the container.
- Evenly place hooked sheets throughout the container. For a 40-foot container, place four hook sets on the left side every 2-3 loops and four hooks on the right side on the opposite hook. Begin inserting Novo-Dry Cargo as close to the time when the container is set to be closed, usually right before loading is set to begin and then seal as soon as possible before shipment.
- Keep cargo container as dry as possible before shipping by using dry pallets and keeping floors and walls dry before closing the container.
- If the recommended amount of Novo-Dry Cargo is used and if the container is airtight, Novo-Dry has been tested to last over 100 days before replacement is needed. Novo-Dry should be replaced at the end of each shipment.
- Minimize the time required to transition Novo-Dry Cargo from its packaging to its end use in an airtight space. 8 hooked sheet sets evenly dispersed is recommended for a 40-foot container, 6 hooked sheet sets evenly dispersed is recommended for a 30-foot container and 4 hooked sheet sets evenly dispersed is recommended for a 20-foot container.
- Contact info@simpledry.com or (425) 200-6800 for specific questions or concerns with the using the product.